things to know

1. Speaker can operate via Bluetooth or by connecting directly to the audio port of your computer.
2. Adjust the switch 'A' at the side the Sprout Bluetooth Speaker to turn on either BT or MicroSD/Line.
3. The battery in the Sprout Cortex is rechargeable. Please remember to recharge regularly, but remove the input cable before charging.
4. Volume can be adjusted by adjusting the volume on the device that you are connecting to the speaker with, such as your MP3 player or phone.
5. Cortex speaker is compatible with all modern Bluetooth devices.
6. If a password is required please enter: 0000

MP3 Mobile Laptop

what's in the pack

Tempo speaker x 1

USB DC input cable

Line cable x 1

specifications:

User manual x 1

Size: 81x49x57mm
Net Weight: 160g
SNR: ≥60dBA
Speakers: D36mm (20Hz-20KHz)
Power output: 3.0W
Audio support: Mp3 WAV
Support Card: TF (2-8G)
Lithium ion battery input: 500mAH/DC 5V
Bluetooth version: compatible with V3.0, V2.1, V2.0, V1.1 and V1.2 standard.
Bluetooth product support: A2DP, AVRCP
Scope: <10 meters of wireless communications
Working Condition: Humidity <80%, 0~45°C
Storage Condition: Humidity <90%, -20~60°C
Battery Use (Fully Charged): Line-in 8Hrs / TF 6Hrs / Bluetooth 4Hrs

controls

Bluetooth Connection Instruction:
Turn switch 'A' to Bluetooth mode and the blue LED will illuminate. Choose Sprout Cortex in your device for connection (If a password is required, please enter: 0000). Once connect, the blue LED will illuminate constantly and you can start using Cortex wirelessly.

Easy Link Cable Instruction:
Turn off the speaker, and then connect USB to PC. Turn switch 'A' to Line-in mode on the speaker. When connected, the speaker will be charging via the USB, and file can be transfer between your device and TF card.
Charging Instruction:

Cortex speaker can be charged via PC or power adapter. Connect the USB DC input cable to the speaker USB port and your PC / power adapter. When charging, the red LED will illuminate and when fully charged, the LED will switch off.

controls



www.sproutinc.com.au

cortex speaker

user manual

sprout™